

## **Light source remove Instructions**

V1.0 Template(2021)

		V 1.0 Template(2021)
Product Identification		Product Image
Company Name	LUTEC	
Item code	5193201118	
Module code	5193201118M	
Product Name	LOTUS	
Last modified	2021/5/10	
Step		
1. Light		2. Unscrew and remove the plastic plate
3. Unscrew and remove the terminal and plastic cover		4. Solder and remove the driver board
5. Unscrew the top screw and remove the		6. Solder and remove the LED panel
7. Spread alcohol around the glass and cut the black glue with a blade to take out the glass		8. Unscrew the reflector
		10 Module
9. Unscrew and remove the LED panel 10. Module		